



**sensor
can**

manual

simplehuman®

We started simplehuman
to help people become
more efficient at home.
All of our products are
ergonomic, easy to clean,
and are designed to last
for years. Learn more at
www.simplehuman.com

IMPORTANT SAFEGUARDS

To reduce the risk of fire, electrical shock, and/or personal injury, always practice basic safety precautions, including the following:

-
1. **Read all instructions before using the sensor can.**
 2. This appliance must be properly installed and located in accordance with these instructions before it is used.
 3. Use this appliance only for its intended purpose as described in the manual. Do not use a power adapter or other accessories not recommended for use by simplehuman® with this product, as this may result in fire, electric shock, or injury to persons.
 4. Do not place near areas or surfaces with extremely high temperatures, such as a hot gas or electric burner.
 5. Do not use outdoors.
 6. To protect against electric shock and internal damage, do not place the appliance in water or any other liquid.
 7. Do not use old or leaky batteries with this appliance.
 8. Turn off the power before putting on or taking off parts or before cleaning.
 9. Before removing the batteries, check that the appliance is not switched on. If it is, turn it off.
 10. Remove the batteries before storing the appliance.
 11. Do not operate the appliance if it is damaged in any manner. Contact simplehuman® Customer Support to arrange for replacement or repair.

-
12. Make sure there is enough room to operate the sensor can without blocking the opening or closing of the lid.
 13. Make sure your sensor can is placed on a steady base to avoid toppling over and damaging the internal mechanism.

SAVE THESE INSTRUCTIONS

WARNING:

1. Do NOT manually force the lid closed – this may damage the internal mechanism that opens the lid.
2. Make sure no objects are obstructing the lid as it opens, as this may damage the lid or the internal mechanism.
3. Close supervision is necessary when any appliance is used by or near children or pets.
4. Keep all plastic bags away from children and pets.
5. If appliance is damaged, it should be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.
6. Do not operate appliance with accessories, replacement parts, or repair services not authorized by simplehuman, as they may damage the sensor can and invalidate the warranty.

IMPORTANT: If your appliance does not work or you have additional questions or concerns, please contact simplehuman Customer Support at (888) 988-8880.

DO NOT RETURN THIS ITEM TO THE STORE OR RETAILER WHERE YOU PURCHASED IT.

TABLE OF CONTENTS

INTRODUCING YOUR SENSOR CAN	6
contents of the box	6
parts of the sensor can	7
special features	8
<hr/>	
USING YOUR SENSOR CAN	11
set up your sensor can	11
operate your sensor can	12
LED indicator diagram	13
hold your sensor can open	14
reset your sensor can	15
manual open	15
simplehuman® can liners	16
changing the bag	17
<hr/>	
CLEANING & MAINTENANCE	18
<hr/>	
TROUBLESHOOTING	20
<hr/>	
LIMITED WARRANTY & SERVICE	22

INTRODUCING YOUR SENSOR CAN


simplehuman® rectangular sensor can

Your new simplehuman® rectangular sensor can features a recessed sensor zone that allows for easy and accurate hands-free operation. The foot-activated sensor eliminates the need to touch your sensor can while performing chores such as preparing foods or cleaning up.

contents of the box

- simplehuman® rectangular sensor can (38 liters/10 gallons)
- instruction manual
- quick start guide


parts of the sensor can



1. lid
2. removable inner bucket
3. LED light
4. recessed sensor zone
5. drive system
6. hold button
7. integrated handles
8. bag tuck™ opening

9. battery cover
10. power adapter jack
11. power switch
12. battery compartment
13. handle

special features




1. recessed sensor zone

The simplehuman® rectangular sensor can features an exclusive sensor design that prevents false triggers – so the lid opens only when you want it to. The recessed sensor zone has a wide area for easy access, but the concave shape keeps the sensor from being activated accidentally, even in high-traffic areas.

2. drive system with smart linkage

The sensor can's drive system is connected to the lid with our exclusive smart linkage design – for smooth, quiet, and seamless operation.


- motion control:
lid opens and closes smoothly without jerky movements
- quiet operation:
dampened drive system minimizes noise when the lid opens and closes
- manual open:
if necessary, you can turn off the power and open the sensor can lid manually (see page 15 for details)



3. lid “hold” button

A “hold” button opens the lid a full 90° and allows you to keep the lid open for extended chores. See page 14 for details.

4. smartbucket® bag change system



The smartbucket® bag change system eliminates messy bag overhang and makes it easier than ever to take out the trash.

A. integrated handles

The integrated handles on the edges of the inner bucket make it easy to lift the bucket.

B. bucket park™

The bucket park™ position holds the bucket in an elevated position while you remove and change the bag. Simply lift and tilt the bucket towards you so that it rests on the inner platform.

C. bag tuck™


The bag tuck™ opening on the inner bucket allows you to tuck away excess bag. This ensures a snug fit and eliminates messy bag overhang on the outside of the can.

5. low battery alert

The sensor can LED light will alert you of low battery power by flashing red while the lid opens or closes – once this occurs, it is time to change the batteries. If batteries are not changed soon, the lid may stop opening or closing and the LED light will stay red until batteries are replaced.

6. optional power adaptor


simplehuman offers a power adaptor that eliminates the need for batteries. Please contact us at support@simplehuman.com or (888) 988-8880 to order.



USING YOUR SENSOR CAN


set up your sensor can

1. Remove your simplehuman® sensor can from the box and place it in the intended area of operation. Make sure the base is steady and the lid has enough room to open freely.



2. Remove the battery cover and insert six "D" batteries into the battery compartment as shown (there is also a battery diagram inside the battery compartment).


operate your sensor can



1. Turn on the power switch by moving it up to the "ON" position. The LED light on the sensor can will flash green momentarily and then turn off. The sensor can is now ready to use.
2. Place your foot in the recessed sensor zone at the base of the can. The lid will open immediately.
3. Once you remove your foot from the sensor zone, the lid will stay open for about 4-5 seconds before closing automatically. If you keep your foot in the sensor zone, the lid will remain open.

WARNING: Do NOT manually force the lid closed – this may damage the internal mechanism that opens the can.

4. If you place your foot in the sensor zone as the lid is closing, the lid will return to the open position.




5. To turn off the can, simply move the power switch down to the "OFF" position.

LED indicator diagram

LED light	what it means
LED light is off	<ul style="list-style-type: none">• Can is operating normally or is turned off.
Flashing red	<ul style="list-style-type: none">• Battery power is low – replace batteries soon.
Constant red	<ul style="list-style-type: none">• Can is on “hold” or has encountered an obstruction. Remove any obstructions and then press the “hold” button for 2 seconds until the LED flashes green twice.• Batteries are low and need to be replaced.
Flashing green	<ul style="list-style-type: none">• Can has been reset or was just turned on.

hold your sensor can open

The “hold” button opens the lid a full 90° and allows you to keep the lid open for extended chores, such as clearing the dishes.



how to “hold” the lid open:

- Press the “hold” button while the lid is open. While the lid is on “hold”, the LED light will turn red and the lid will remain open.


how to take the lid off “hold” and close the lid:

- Press the “hold” button for 2 seconds until the LED light flashes green twice. The lid will close automatically and normal operation will resume.

WARNING: Do NOT manually force the lid closed – this may damage the internal mechanism that opens the can.

reset your sensor can

The “hold” button also acts as the “reset” button for your sensor can. If the lid is obstructed by an object while it is opening, the lid may not function normally and the LED light will become red. If the lid encounters an obstruction while closing it will return to the open position and LED light will become red. If this occurs, check for and remove any obstructions and then reset the sensor can as described below.




how to reset your sensor can

1. Press the “hold” button for 2 seconds. The LED light will flash green twice.
2. The lid will close automatically, and the can will reset itself.

WARNING: Do NOT manually force the lid closed – this may damage the internal mechanism that opens the can.

manual open

If for some reason you need to open the sensor can but cannot use the sensor (for example, if there is insufficient battery power), you can open the lid manually instead.



1. Make sure the lid is completely closed.
2. Turn off the power by flipping the power switch to the “OFF” position.
3. Lift the lid open and close the lid manually.

simplehuman® can liners

Your simplehuman® sensor can is designed to work with standard kitchen bags, but we've introduced our simplehuman® can liners for added durability and a perfect fit. simplehuman® can liners have an extra durable double seal, convenient drawstring handles, and are the perfect size for your simplehuman® sensor can.


Your simplehuman® rectangular sensor can works with simplehuman® can liners code J.

We've included a trial pack of our simplehuman® can liners with your sensor can. To purchase additional simplehuman® can liners, please visit our online store at www.simplehuman.com.

changing the bag



1. Open the sensor can lid by inserting your foot in the sensor zone.




2. Press the "hold" button to open the lid a full 90° and keep the lid open.



3. Remove the inner bucket or place the bucket in bucket park™ position by lifting it halfway and tilting the top of the bucket towards you. Allow the bucket to rest on the inner platform inside the can.



4. Remove the old bag (if necessary) and insert a new bag in the removable inner bucket. Your sensor can works with both regular tall kitchen bags and simplehuman® can liners code J. If using a regular bag, tuck the excess bag into the bag tuck™ opening on the bucket for a secure fit.



5. Return the inner bucket back inside the can, and release the lid from "hold" by pressing the "hold" button for 2 seconds until the LED light flashes green twice.

CLEANING & MAINTENANCE

With the proper maintenance, your simplehuman® stainless steel sensor can is designed to last for years. We've created this guide to help you care for your stainless steel product.

cleaning stainless steel

It is recommended that stainless steel be cleaned regularly with water and a soft cloth, such as our microfiber sponge mitt; this will prevent new stains from building up. For a more thorough cleaning, you can use water and mild detergent instead. After you are done, rinse with clean water and wipe dry with a soft absorbent cloth.

fingerprints, oil and grease marks

Fingerprints can be easily removed by cleaning with water and a soft cloth, such as our microfiber sponge mitt. Simply wet one side with water and use the dry side to wipe and polish. If water does not do the trick, you can use mild dishwashing detergent or glass cleaner in its place. If you use chemical cleaners or detergents, always rinse your product afterwards with clean water and dry with a soft cloth.

rusting

With the proper care, your stainless steel sensor can should easily resist rust. Do not expose your sensor can to water or other liquids for prolonged periods of time. If rusting does occur, it can be removed by applying a cream cleanser such as MAAS® polish and rubbing gently with a damp cloth. If the rust is stubborn, a proprietary stainless steel cleaner may be needed to remove it completely. Since these cleaners may contain dangerous chemicals, please take proper precautions and always follow the manufacturer's directions. If the rust cannot be removed with these suggestions, you can always have it removed professionally.

sticky residue from labels

The residue left from labels on stainless steel can be easily removed by applying adhesive removers such as "Goo-Gone®", "Un-du®", or "De-solv-it®". After applying the remover and completely removing all residue, rinse with water and dry with a soft cloth.

never use these on stainless steel

Some products may damage stainless steel and should never come in contact with your stainless steel product:

- Do not use steel wool to wipe your stainless steel products, as it will scratch the surface.
- Never clean stainless steel products with bleach - it will discolor the product.
- Avoid contact with salts and acids - these will also discolor the product if left on for a long period of time.

TROUBLESHOOTING

what's wrong	how to fix it
lid will not open	<p>LED light is off</p> <ul style="list-style-type: none">• Make sure the power switch is in the "ON" position and the batteries are inserted correctly.• Battery power may be low. Replace the batteries.
	<p>LED light is red</p> <ul style="list-style-type: none">• If something blocked the lid from opening, remove the item. Then press the "hold" button for 2 seconds to reset the can.• Battery power may be low. Replace the batteries.
lid will not close	<p>LED light is off</p> <ul style="list-style-type: none">• Check that there are no objects in the sensor area. If there are, remove them.• If something blocked the lid from closing, remove the item. Then press the "hold" button for 2 seconds to reset the can.• Make sure the power switch is in the "ON" position and the batteries are inserted correctly.

what's wrong	how to fix it
lid will not close (continued)	LED light is red <ul style="list-style-type: none"><li data-bbox="614 458 1011 582">• The lid may have been put on "hold" while the lid was open. Press the "hold" button for 2 seconds to deactivate.<li data-bbox="614 606 1022 729">• If something blocked the lid from closing, remove the item. Then press the "hold" button for 2 seconds to reset the can.
lid only opened partway	<ul style="list-style-type: none"><li data-bbox="614 745 1030 868">• If something blocked the lid from opening, remove the item. Then press the "hold" button for 2 seconds to reset the can.
LED light flashes red when lid opens or closes	<ul style="list-style-type: none"><li data-bbox="614 883 1011 945">• Battery power is low. Replace the batteries.
LED light stays red while the lid is closed	<ul style="list-style-type: none"><li data-bbox="614 960 1011 1022">• Battery power is low. Replace the batteries.

If your appliance still does not work or you have additional questions, please contact simplehuman Customer Support at (888) 988-8880.

DO NOT RETURN THIS ITEM TO THE STORE OR RETAILER WHERE YOU PURCHASED IT.

LIMITED WARRANTY & SERVICE

simplehuman warrants this simplehuman product for 1 year from the date of purchase against defects in material and workmanship, and agrees to repair or replace any defective item. If a replacement product is sent, it will carry the remaining warranty of the original product.

Your simplehuman product has been manufactured to strict specifications and has been designed for use with simplehuman authorized accessories and replacement parts. These warranties expressly exclude any defects or damages caused by accessories, replacement parts or repair service other than those authorized by simplehuman. simplehuman will not pay for warranty service performed by a non-authorized repair service and will not reimburse the consumer for damage resulting from warranty service performed by a non-authorized repair service. Warranty excludes all incidental or consequential damages that result from user mishandling, accident, misuse or abuse, lack of reasonable care, the affixing of any attachment not provided with the product or loss of parts or subjecting the product to any but the specified voltage, or use of a simplehuman product in other than its intended, household capacity.

A copy of your dated proof of purchase is required prior to any and all claims under these warranties. To provide better service we would appreciate that you complete the on-line warranty registration form. Warranty is available on consumer retail purchase only. Specially discounted and/or discontinued merchandise is not covered under this program. This warranty is not available to retailers or other commercial purchasers or owners.

NOTE: No other warranty, written or oral, is authorized by simplehuman.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion and limitations may not apply to you.

If you have questions concerning your warranty coverage or the status of your warranty registration, please visit or call:

www.simplehuman.com
phone: (888) 988-8880

If you would like to obtain warranty service, simply take or ship the product postage prepaid to*:

simplehuman
Warranty Coverage Service
19801 S. Vermont Avenue
Torrance, CA 90502

*It is suggested that for your protection you return shipments of product by insured mail, insurance prepaid. Damage occurring during shipment is not covered by this warranty.

Manufactured for:
simplehuman®
19801 S. Vermont Avenue
Torrance, CA 90502

tools for efficient living®

simplehuman®

www.simplehuman.com

888.988.8880